

GARANT Protection

Family owned business in 3rd generation

Since more than **70 years** in the market (1st patent 1953)

Based in Switzerland & Germany

Worldwide activities

Inhouse R&D + Manufacturing + Distribution

NATO-Supplier

Aircraft Industry Supplier

ISO 9001:2015

Trademarks: GARANT®, SPS®, TiG®, FlexLiner®, FirmLiner®











EOD/IEDD Products – PPE & other protection equipment





















EOD/IEDD Products – Bomb Suit History





EOD/IEDD Bomb Suits & Search Suits



SPS-15 Bomb Suit



SPS-10a Bomb Suit



TPS-600 ModularTactical Suit



LPS-475 Search Suit




EOD/IEDD Bomb Suit SPS-15





EOD/IEDD Bomb Suits & Search Suits – 360° Protection Principle





EOD/IEDD Fragmentation Protection

Bomb Suit originally designed as Fragment Protection Suit

Fragmentation Protection is one of the most important purposes of a «Bomb Suit»


Fragments can occur in different

shapes (pre-shaped / donation shaped)
weights
velocities
angles
materials

Human Tolerance to fragment impact is very low.




Figure 10. Open sources. Internet






EOD/IEDD Fragmentation Protection







V50-Testing acc. STANAG 2920 resp. MIL-SPEC-662F resp. STANAG 4569

0.325g (5gr.) - 1.1g (17gr.) - 2.84g (44gr.) - 13.39g (207gr.) & 52.73g (814 gr.)

1

2

3

4


5



Fig. 10.15 Bowen pulmonary iso-injury curves (70 kg man with long axis of the body perpendicular to the blast wave propagation) (adapted from Bowen et al. 1968)



The pressure tolerance for shortduration blast loads is significantly higher than for long-duration blast loads.







Human related pressure results


 \Rightarrow not only measurment of pressure reduction!


⇒ Axelson-Criterion

⇒ measurment of complex blast waves (reflecting and over-lapping blast waves)









Injury Level	ASII	V (m/s)	AIS Range
no <u>iniury</u>	0,0 - 0,2	0,0 - 3,6	0
trace to slight	0,2 - 1,0	3,6 - 7,5	1 - 4
slight to moderate	0,3 - 1,9	4,3 - 9,8	2 - 4
moderate to extensive	1,0 - 7,1	7,5 - 16,9	3 - 5
>50% lethality	> 3,6	> 12,8	- 6





Hybrid III

VS.

Primus

OR

Hybrid III

and

Primus

?!?







Hybrid III



Primus
















0,567kg C4 @ 0.6m - 2x SPS-15





10.00kg C4 @ 3.0m – 2x SPS-15





1x HG-85 @ 0.6m - 1x TPS-600















For now

Hybrid III

<u>and</u>

Primus





